

Soiled linen range

# Dirty linen collection trolleys

Non contractual photos

In order to collect dirty linen in your establishment, we propose **trolleys with fixed or spring-loaded bottom**.

Our trolleys with fixed bottom are equipped with a lid and a drop-down door mounted on hinges. The lid is made of 2 parts: 1/3 is fixed and 2/3 can open until 130°.

On another hand, our trolleys with spring-loaded bottom are composed of a tray which goes up or down according to the load. This system works with a spring and considerably improves staff work conditions.



Robust



Hygienic



Ergonomic

## Key points

- ▶ Strong frame
- ▶ Handy
- ▶ Light
- ▶ Fixed or spring-loaded bottom

## Soiled linen range

# Dirty linen collection trolleys

### Trolleys with fixed bottom

- ▶ Anodised aluminium alloy trolley body
- ▶ Very strong torsion-resistant frame
- ▶ Lateral rubber bumpers
- ▶ 2/3 lid opening with safety stop in open position
- ▶ Drain valve
- ▶ Double lateral handle on fixed wheel side
- ▶ 4 Ø 160 mm wheels (2 fixed and 2 swivel wheels without brake)
- ▶ Non-marking rubber tires

Description	Dimensions (in mm)	Reference
<b>699-litre collection trolley</b>	L. 1100 x D. 650 x H. 1425	AF12020
<b>987-litre collection trolley</b>	L. 1400 x D. 760 x H. 1340	AF12021



### Trolleys with spring-loaded bottom

- ▶ Anodised aluminium alloy trolleys
- ▶ Very strong torsion-resistant frame
- ▶ Lateral rubber bumpers
- ▶ 4 Ø 125 mm castors, arranged at the angle (2 fixed and 2 swivel wheels without brake)
- ▶ Non-marking rubber tires

Description	Dimensions (in mm)	Reference
<b>223-litre spring-loaded bottom trolley</b>	L. 1080 x D. 450 x H. 770	AF12000
<b>336-litre spring-loaded bottom trolley</b>	L. 1080 x D. 630 x H. 800	AF12001
<b>Optional 4 swivel wheels</b>		AF00301

